


Time of Sale

Extended Protection



Peace of mind.

Canada & United States Coverage

FCPP covers your vehicle anywhere in Canada and the continental United States.

Direct Response

FCPP will quickly and efficiently handle your claim. Repair costs are paid directly to the repair facility on authorized services, saving you from out-of-pocket expenses and the inconvenience of waiting for reimbursement.

Transferable Coverage

In the event you choose to sell your vehicle, you can apply to transfer the coverage to the next owner for the remainder of the plan term.

Deductible

Plans have a choice of \$100 or \$200 deductible per repair visit, plus applicable taxes, on all covered repairs. In the event the same component fails again, no deductible will be charged for its repair or replacement.

Reducing Deductible

The selected deductible will be reduced by \$50 when repairs are performed at your selling dealer.

Experienced Based Refund (EBR)/Guaranteed Price Rebate (GPR)

(Available on qualifying plans)

If the plan you select includes EBR/GPR, you can apply for a refund as soon as the plan expires by time. Refunds are based on the amount you originally paid for the plan, up to a maximum of \$2,000, less your deductible.



Travel with peace of mind.

Travel with a First Canadian Protection Plan.

Are you worried about unexpected breakdowns and unforeseen costly repairs? With the cost of service and components increasing each year, an expensive repair can be a major financial burden. **Leave your worries behind with FCPP.**

- FCPP will quickly and efficiently handle your claim. **Repair costs are paid directly to the repair facility on authorized services**, saving you from out-of-pocket expenses and the inconvenience of waiting for reimbursement.
- Choose a protection plan that guards against these unplanned expenses.

It's better to have protection and NOT NEED it, than to NEED it and NOT HAVE ANY.



Select the right plan for You.

	Powertrain	Select Plus	Ultimate
Engine	●	●	●
Turbocharger/Supercharger	●	●	●
Transmission	●	●	●
Transfer Case	●	●	●
Drive Axle	●	●	●
Front Wheel Steering		●	●
Brakes		●	●
Electrical		●	●
Air Conditioner		●	●
Fuel System		●	●
Front & Rear Suspension		●	●
Heating/Cooling System		●	●
Emission System		●	●
Electric/Hybrid Vehicles			●
Ultimate Parts Group			●





First Canadian Protection Plans


TOLL FREE 1.800.381.2580


Schedule of Coverage


Includes parts and labour for the following components:


 ENGINE	Powertrain	Select Plus	Ultimate
Cylinder block & all internal lubricated parts contained within the engine	●	●	●
Cylinder Heads	●	●	●
Pistons & Piston Rings	●	●	●
Connecting Rods & Bearings	●	●	●
Crankshaft & Crankshaft Main Bearings	●	●	●
OHC Carriers	●	●	●
Cover & Module	●	●	●
Camshaft & Camshaft Bearings	●	●	●
Cam Followers	●	●	●
Timing Chain/Belt (unless timing belt was not replaced when recommended by the manufacturer)	●	●	●
Timing Gears	●	●	●
Timing Chain Cover	●	●	●
Timing Chain Tensioners	●	●	●
Timing Chain & Belt Guides	●	●	●
Timing Belt Pulley	●	●	●
Engine Serpentine Belt Tensioner	●	●	●
Idle Pulley & Idle Pulley Bearings	●	●	●
Flywheel (excluding teeth)	●	●	●
Rocker Arms & Rocker Shafts	●	●	●
Rocker Bearings	●	●	●
Cylinder Head Valves	●	●	●
Valve Seals & Valve Seats	●	●	●
Valve Lifters & Valve Springs	●	●	●
Valve Retainers	●	●	●
Push Rods	●	●	●
Water Pump	●	●	●
Oil Pump & Oil Pump Housing	●	●	●
Harmonic Balancer	●	●	●
Oil Pan (excluding drain plug threads)	●	●	●
Intake Manifold	●	●	●
Exhaust Manifold (excluding manifold & convertor assembly)	●	●	●
Valve Covers	●	●	●
Engine Mounts	●	●	●
Diesel Fuel Injection Pump	●	●	●
Diesel Vacuum Pump	●	●	●
Seals & Gaskets*	●	●	●


 TURBOCHARGER /SUPERCHARGER	Powertrain	Select Plus	Ultimate
Turbocharger/Supercharger Housing & all internal parts	●	●	●
Blowout Valves	●	●	●
Intercooler	●	●	●
Seals & Gaskets*	●	●	●


 TRANSMISSION (Automatic and Standard)	Powertrain	Select Plus	Ultimate
Transmission case (if damaged from within) & all internal parts	●	●	●
Input Shaft	●	●	●
Master Clutch Cylinder	●	●	●
Torque Converter	●	●	●
Vacuum Modulator	●	●	●
Transmission Mounts	●	●	●
Oil Pan	●	●	●
Seals & Gaskets*	●	●	●

 TRANSFER CASE	Powertrain	Select Plus	Ultimate
Transfer Case (if damaged from within) & all internal parts	●	●	●
Encoder Motor	●	●	●
Seals & Gaskets*	●	●	●

 DRIVE AXLE (Front and Rear)	Powertrain	Select Plus	Ultimate
Final Drive Housing	●	●	●
Drive Axle Case (if damaged from within) & all internally lubricated parts.	●	●	●
Differential Cover	●	●	●
Axle Shaft	●	●	●
Drive Shaft Universal Joint	●	●	●
Wheel Bearings	●	●	●
Hub Bearing Assembly (unless failure is caused by anti-lock breaking system)	●	●	●
Tapered Wheel Bearings	●	●	●
Locking Hubs	●	●	●
Drive Shaft	●	●	●
CV (Constant Velocity) Joints	●	●	●
Drive Line Actuators	●	●	●
CV Boots	●	●	●
Seals & Gaskets*	●	●	●

 FRONT WHEEL STEERING	Powertrain	Select Plus	Ultimate
Steering Box & all internal parts		●	●
Rack & Pinion Gear		●	●
Power Steering Pump		●	●
Power Steering Hoses		●	●
Steering Spindles		●	●
Pitman Arm		●	●
Idler Arm		●	●
Center Link		●	●
Upper Steering Column Shaft		●	●
Relays		●	●
Sensors		●	●
Seals & Gaskets*		●	●


 BRAKES	Powertrain	Select Plus	Ultimate
Master Cylinder		●	●
Vacuum Assist Booster		●	●
Hydro Assist Booster		●	●
Disc Brake Caliper		●	●
Wheel Cylinders		●	●
Compensating Valve		●	●
Metal Brake Hydraulic Lines		●	●
Combination Valve		●	●
Seals & Gaskets*		●	●


 ELECTRICAL	Powertrain	Select Plus	Ultimate
Alternator		●	●
Digital Instrument Cluster		●	●
Instrument Panel Printed Circuit Board		●	●
Voltage Regulator		●	●
Starter Motor		●	●
Starter Solenoid		●	●
Starter Drive		●	●
Factory Engine Compartment Wiring Harness		●	●
Electronic Ignition Module		●	●
Distributor Pick-up Coil		●	●
Ignition Switch		●	●
Ignition Lock Cylinder		●	●
Ignition Coils		●	●
Front & Rear Wiper Motor		●	●
Washer Pump & Switch		●	●
Manually Operated Electrical Switches		●	●
Body Computer & Control Module		●	●


*Seals & Gaskets coverage means coverage of excessive leakage for all seals and gaskets listed for the plan selected that contain fluids or lubricants.


Schedule of Coverage


Includes parts and labour for the following components:


 ELECTRICAL (Cont.)	Powertrain	Select Plus	Ultimate
Powertrain Control Module		●	●
Stop Lamp Switch		●	●
Headlamp Switch & Motor		●	●
Turn Signal Switch		●	●
Heater & Air Conditioning Control Assembly		●	●
Blower Motor Resistor		●	●
Horns		●	●
Factory Installed Cruise Control Module		●	●
Cruise Control Transducer		●	●
Cruise Control Servo & Amplifier		●	●
Cruise Control Engagement Switch		●	●
Power Vent Window Motors		●	●
Power Window Motor (excluding regulators)		●	●
Power Window Switch		●	●
Serviceable Power Seat Motors (excluding frame/base assembly)		●	●
Power Seat Switch		●	●
Power Mirror Motor (excluding assemblies)		●	●
Power Mirror Motor Switch		●	●
Power Antenna Motor (excluding mast)		●	●
Convertible Top Motor		●	●
Serviceable Sun Roof Motor (excluding frame assembly)		●	●
Rear Defogger Switch		●	●
Rear Window Defroster Grid (excluding glass)		●	●
Power Door Lock Actuator & Switch		●	●


 AIR CONDITIONER	Powertrain	Select Plus	Ultimate
Condenser		●	●
Compressor		●	●
Clutch Assembly & Pulley		●	●
A/C Lines & Hoses		●	●
Evaporator		●	●
High/Low Compressor Cut-off Switch		●	●
Expansion Valve		●	●
Pressure Cycling Switch		●	●
Orifice Tube		●	●
Seals & Gaskets*		●	●


 FUEL SYSTEM	Powertrain	Select Plus	Ultimate
Fuel Pump		●	●
Diesel Fuel Injectors/Nozzles		●	●
Fuel Tank		●	●
Mechanical Fuel Tank Sending Unit		●	●
Fuel Rail		●	●
Fuel Pressure Regulator		●	●
Metal Fuel Delivery Lines		●	●
Fuel Tank Selector Valve		●	●


 FRONT & REAR SUSPENSION	Powertrain	Select Plus	Ultimate
Upper & Lower Control Arms		●	●
Control Arm Shafts/Bushings		●	●
Upper & Lower Ball Joints		●	●
Torsion Bars & Mounts/Bushings		●	●
Stabilizer Bar (excluding any electronic disconnect system)		●	●
Stabilizer Links & Bushings		●	●
King Pins		●	●
Spindle & Spindle Support		●	●

 HEATING & COOLING SYSTEM	Powertrain	Select Plus	Ultimate
Heater Core		●	●
Front & Rear Blower Motor		●	●
Engine Cooling Fan & Motor		●	●
Hydraulic Fan Clutch Hub		●	●
Radiator		●	●
Hot Water Valve		●	●

 EMISSION SYSTEM	Powertrain	Select Plus	Ultimate
Air Pump		●	●
Cam Shaft Sensor		●	●
Canister Purge Solenoid		●	●
Canister Vent Solenoid (excluding the canister filter assembly)		●	●
Knock Sensor		●	●
Crank Angle Sensor		●	●
EGR Solenoid		●	●
EGR Valve		●	●
Idle Speed Control Motor		●	●

 EMISSION SYSTEM (Cont.)	Powertrain	Select Plus	Ultimate
Mass Air Flow Sensor		●	●
Manifold Pressure Sensor		●	●
O2 (Oxygen) Sensor		●	●
PCM Coolant Temperature Sensor		●	●
Serviceable Throttle Position Sensor (TPS)		●	●
Vacuum Pump		●	●
Emission System Coverage Extension Ultimate plans extend the period of coverage for the Emission System from an odometer reading of 100,000km to 140,000km.			●

 ELECTRIC/HYBRID VEHICLES	Powertrain	Select Plus	Ultimate
Batteries & Battery Packs (up to \$10,000, excludes battery degradation)			●
Home Charging Unit (1 repair or replacement, up to \$800)			●
All mechanical system parts or components are covered unless specifically list as not covered. Some examples of extra covered components are:			
Electric Power Control Modules			●
Electric Motor Controller			●

 ULTIMATE PARTS GROUP	Powertrain	Select Plus	Ultimate
Block Heater			●
Transmission Cooler Lines			●
Hub Bearing Assemblies			●
Steering Wheel			●
Power Steering Cooler			●
ABS Sensor and Wiring Harness			●
Park Brake Cables			●
Complete Vehicle Wiring Harness			●
Radio			●
Rear Seat Media System			●
Navigation Systems			●
Window Regulators			●
Heated Seats			●
Daytime Running Light Module			●
Fuel Level Sensor			●
Fuel Gauge			●
Coolant Reservoir			●
Radiator Cap			●

*Seals & Gaskets coverage means coverage of excessive leakage for all seals and gaskets listed for the plan selected that contain fluids or lubricants.



Schedule of Coverage

WHAT'S NOT COVERED?

Throttle body; start light ignition batteries; zippers; windshield wiper arms and linkage assembly; headlamp; projection lamp and tail-lamp assemblies; cup holders; ashtrays; dash pads; consoles; seat frames and springs; convertible top and convertible top frame structures (provided, however, that cables, motors, electronics and switches associated with the functioning of the convertible top are included in the Ultimate coverage); inside and outside door handles and hinges; shock absorbers; MacPherson strut assembly (including upper mounts and bearings); pipes and hoses (except steering and air conditioning pipes and hoses), lines and rubber brake hoses (except power steering pressure hoses, steel air conditioning lines, and steel brake lines); fastening devices such as clips, nuts, bolts, fasteners, and rivets; standard transmission clutch assembly; manual clutch disc or pressure plate and related bushings and bearings; manual and hydraulic linkages; corroded cables; secondary ignition components; glass (including mirror assemblies and heated windshields); lenses; sealed beams; light bulbs; sockets; fuses; cellular phones; brake rotors and drums; components of exhaust and emission systems not specifically identified as part of the Emission System component group; components of any lift kit; catalytic converter; weather strips; run channels; trim; moldings; bright metal; chrome; upholstery and carpet; paint; outside ornamentation; bumpers; body sheet metal and panels; structural body parts; sun roof frame and assemblies; tires; wheels and rims; and wheel or rim-mounted sensors.

If a lift kit is installed, ball joints, universal joints, steady bearings, wheel bearing, and hub assemblies will be excluded from all coverage plans.

Additional Benefits Included in All Levels of Coverage

No deductible will apply

ROAD SERVICE & TOWING



If your vehicle is unable to proceed safely under its own power, we will pay to tow the vehicle to the dealer (up to \$240) or to another destination (up to \$100). Additional services include mechanical first aid, tire service, battery service, fuel delivery service, and locksmith service.

RENTAL



In the event of a covered breakdown requiring overnight repairs, we will pay to reimburse you for receipted expenses to rent a replacement vehicle or reimburse you for taxi or public transportation expenses. Up to \$50 per day, maximum of \$250 per repair.

TRIP INTERRUPTION



In the event a covered breakdown occurs more than 100km from your home and results in a repair facility keeping your vehicle overnight, we will reimburse receipted motel and restaurant expenses. Up to \$150 per day, maximum \$450 per repair.



**Mechanical Breakdown Contracts
Administrator / Obligor**

First Canadian Repair Protection
320 Sioux Road
Sherwood Park, AB T8A 3X6
Toll-Free PH: 1.800.381.2580



**Mechanical Breakdown Policies
Administrator / Underwriter**

Millennium Insurance Corporation
320 Sioux Road
Sherwood Park, AB T8A 3X6
Toll-Free PH: 1.800.381.2580

Admin

Local PH: 1.780.410-4508
MechanicalAdmin@firstcanadian.ca

Claims

Local PH: 780-410-4546
mechanicalclaim@firstcanadian.ca

*NOTICE: The contents provided in this brochure are only a summary of certain terms and conditions of the plan. Please refer to the actual plan for complete details of coverage and exclusions. Not all plans are available in all provinces, and specific provisions may vary based upon individual provincial requirements.